



BULLOCK

www.bullockmfg.com.au

MODEL 4900 MASONRY WALL WITH METAL GAP SPACERS


Masonry Wall With Metal Expansion Gap Spacers

Drawing 4900-1

INSTALLATION INSTRUCTIONS

FRL - / 240 / -

1. **INITIAL DAMPER TEST** Before installing damper into wall, check damper's closing operation. This can be achieved by placing the damper in an upright position. Hold blade stack whilst removing UL33 rated fusible link. Let the curtain blade stack fall. Gather blades up and return fusible link to its original position.
2. Ensure the wall penetration is the correct size. Refer to AS1682.2-1990 Appendix 'C'
3. Remove flange screw/bolts and detach flanges from damper casing.
4. Slide damper with metal seal attached into penetration.
5. Replace flanges making sure damper is fixed firmly within the wall. **NOTE: Do not overtighten flange screw/bolts.**
6. Repeat **INITIAL DAMPER TEST** - "POINT #1".
7. Connect ductwork to fire damper using fire resistant mastic to fill recess if using raw edge connection, or apply mastic to both surfaces of the TDF/TDC flange connections. (Bolts must be of a low melting point material). Refer to AS4254/AS1668 Standards if required.



MAINTENANCE INSTRUCTIONS

All Fire Dampers shall be accessible and maintained in accordance with AS1851.6

Your local representatives details can be located at www.bullockmfg.com.au



BULLOCK
www.bullockmfg.com.au