



## MODEL 4900 MASONRY WALL WITH METAL GAP SPACERS


Masonry Wall With Metal Expansion Gap Spacers

Drawing 4900-1

INSTALLATION INSTRUCTIONS

FRL - / 240 / -

- 1. INITIAL DAMPER TEST** Before installing damper into wall, check damper's closing operation. This can be achieved by placing the damper in an upright position. Hold blade stack whilst removing UL33 rated fusible link. Let the curtain blade stack fall. Gather blades up and return fusible link to its original position.
- 2. "Bricking in".** Advise builder of damper location and direction fo airflow. Damper should be laid on a 3mm to 4mm thick mortar.  
**NOTE:** Dampers are clearly labelled with "**AIRFLOW**" direction and "**TOP**" of unit.
- 3.** Complete brickwork around and over damper filling gap between brickwork and damper with a thin layer of mortar.
- 4.** Repeat **INITIAL DAMPER TEST** - "POINT #1".
- 5.** Connect ductwork to fire damper using fire resistant mastic to fill recess if using raw edge connection, or apply mastic to both surfaces of the TDF/TDC flange connections. (Bolts must be of a low melting point material).



### MAINTENANCE INSTRUCTIONS

All Fire Dampers shall be accessible and maintained in accordance with AS1851.6

Your local representatives details can be located at [www.bullockmfg.com.au](http://www.bullockmfg.com.au)

